



Intel® SoC Watch for Linux*

Release Notes

June 2020

Version 2020.3

Intel Corporation

www.intel.com

[Legal Information](#)

Contents

Legal Information	3
Version History	4
Customer Support.....	5
Chapter 1: Introduction	
Chapter 2: New in This Release	
Chapter 3: System Requirements	
Supported Architectures	8
Dependencies	8
Chapter 4: Where to Find the Release	
Chapter 5: Installation Notes	
Intel SoC Watch Prerequisites for Yocto and Wind River* Linux	10
Extracting the Intel SoC Watch Package.....	11
Build the Kernel Modules	11
Building Linux* Kernel Modules	11
Install Intel SoC Watch.....	11
Intel SoC Watch for Linux* Installation.....	12
Prerequisites for FPGA metric collection using Intel SoC Watch	12
Key Files	12
Remove the Intel SoC Watch Drivers	13
Chapter 6: Fixed Issues	
Chapter 7: Known Issues	
Chapter 8: Related Documentation	

Legal Information

Intel technologies may require enabled hardware, software or service activation.

No product or component can be absolutely secure.

Your costs and results may vary.

© Intel Corporation. Intel, the Intel logo, and other Intel marks are trademarks of Intel Corporation or its subsidiaries. Other names and brands may be claimed as the property of others.

Intel's compilers may or may not optimize to the same degree for non-Intel microprocessors for optimizations that are not unique to Intel microprocessors. These optimizations include SSE2, SSE3, and SSSE3 instruction sets and other optimizations. Intel does not guarantee the availability, functionality, or effectiveness of any optimization on microprocessors not manufactured by Intel. Microprocessor-dependent optimizations in this product are intended for use with Intel microprocessors. Certain optimizations not specific to Intel microarchitecture are reserved for Intel microprocessors. Please refer to the applicable product User and Reference Guides for more information regarding the specific instruction sets covered by this notice.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Intel, the Intel logo, Intel Atom, Intel Core, Intel Xeon Phi, VTune and Xeon are trademarks of Intel Corporation in the U.S. and/or other countries.

Microsoft, Windows, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Java is a registered trademark of Oracle and/or its affiliates.

OpenCL and the OpenCL logo are trademarks of Apple Inc. used by permission by Khronos.

© **Intel Corporation**

Version History

These are the main releases of Intel® SoC Watch:

Date	Revision	Description
June, 2019	2.11	Improves handling of unrecognized CPUs, reporting S-state when hibernation occurs, and other bug fixes.
September, 2019	2019.12	Added support for Intel platform code named Ice Lake. Modified hw-cpu-pstate reporting.
October, 2019	2019.13	Fixed issue in hw-cpu-pstate for Intel platform code named Ice Lake.
November, 2019	2020.1	Added support for Intel platform code named Comet Lake.
February, 2020	2020.2	Added collection of tool usage analytics. Added new features pch-slps0, pch-slps0-dbg. Improved error messages and help output. Enhanced driver security.
June, 2020	2020.3	Bug fix release.

Customer Support

For technical support, including answers to questions not addressed in this product, see the Intel System Studio forum (<https://software.intel.com/en-us/forums/intel-system-studio>).

Introduction

Intel® SoC Watch is a data collector for power-related data that can help identify issues on a platform that prevent entry to power-saving states. Captured metrics include:

- System sleep states
- CPU and GPU sleep states
- Processor frequencies
- Temperature data
- Device sleep states

You can correlate the collected data and visualize over time using Intel®VTune Profiler.

This document provides system requirements, installation instructions, issues and limitations, and legal information.

To learn more about this product, see:

- New features listed in the [New in This Release](#) section below, or in the help.
- Reference documentation listed in the [Related Documentation](#) section below
- Installation instructions can be found in the [Installation Notes](#) section below.
- For a detailed quick start guide to running the tool, see the *Intel SoC Watch User's Guide* in your installed documentation.

Optimization Notice

Intel's compilers may or may not optimize to the same degree for non-Intel microprocessors for optimizations that are not unique to Intel microprocessors. These optimizations include SSE2, SSE3, and SSSE3 instruction sets and other optimizations. Intel does not guarantee the availability, functionality, or effectiveness of any optimization on microprocessors not manufactured by Intel. Microprocessor-dependent optimizations in this product are intended for use with Intel microprocessors. Certain optimizations not specific to Intel microarchitecture are reserved for Intel microprocessors. Please refer to the applicable product User and Reference Guides for more information regarding the specific instruction sets covered by this notice.

Notice revision #20110804

2

New in This Release

The 2020.3 release (driver v2.12.1) contains these changes:

- Enabled Graphics Slice Concurrency report when using `-f hw-igfx-cstate`
- The `--help` command now lists option `--no-post-processing` which can be used to delay post-processing. If this is specified on the collection command line, no summary .csv file will be generated at the end of that collection. To generate a summary result or any other result file later, re-process the collection using the `-i` option. Delaying post-processing of large collections (i.e., many metrics and/or long collection duration) until the intermediate collection files (.sw2 or .etl) have been copied to a more powerful system can significantly reduce the post-processing time.
- Intel SoC Watch can be executed without administrative privilege when re-processing results from a previous collection using option `-i`.
- The following old platforms will have support removed in the next release: Intel platforms formerly code named Anniedale, Valleyview, Cherry Trail, Haswell, and Broadwell. (Note: The `pch-ip-active` feature is currently broken for the Broadwell platform and will not be fixed.)
- Support for `socperf` collection of signal-based metrics ended with Intel platform code named Cherry Trail (and limited support for Intel platform code named Apollo Lake), therefore it will be removed in the next release. This will result in removal of all signal-based metrics: `all-approx-bw`, `cpu-ddr-mod0-bw`, `cpu-ddr-mod1-bw`, `disp-ddr-bw`, `dram-srr`, `gfx-ddr-bw`, `io-bw`, `isp-ddr-bw`, `netip-bw`, and `netip-partials-bw`.

System Requirements

Supported Architectures

Intel SoC Watch supports these Intel microarchitecture or platform code names:

- Anniedale
- Cherryview (Cherry Trail)
- Denverton
- Apollo Lake
- Gemini Lake
- Broadwell
- Skylake
- Kaby Lake
- Coffee Lake
- Whiskey Lake
- Amber Lake
- Comet Lake
- Ice Lake
- Skylake-Xeon
- Cascade Lake-Xeon

Dependencies

Intel SoC Watch depends on specific OS configurations and hardware capabilities. If these are not present on the target system, Intel SoC Watch may fail to work properly.

- Linux Kernel version needs to be 2.6.32 or later.
- GNU C Library version must be GLIBC_2.17 or later.
- `KERNEL_CONFIG_TRACEPOINTS` must be enabled.
- Kernel should be compiled with "`CONFIG_MODULES`" enabled.
- P States
 - Kernel config `CONFIG_X86_SFI_CPUFREQ` or `CONFIG_X86_ACPI_CPUFREQ` must be enabled (i.e. set to 'y' or 'm').
 - One of these pstate drivers must be utilized: `sfi-cpufreq`, `acpi-cpufreq`, or `intel_pstate`. To determine which driver is loaded, check the `sysfs /sys/devices/system/cpu/cpu0/cpufreq/scaling_driver` file.
 - If one of these pstate drivers is not loaded, the kernel needs to be reconfigured and recompiled.
- C States
 - Kernel config `CONFIG_TIMER_STATS` must be enabled.
 - Kernel config `CONFIG_INTEL_IDLE` must be enabled and the `intel_idle` kernel module has to support the core of the target platform.
 - To determine if the `intel_idle` kernel module is loaded, check the `sysfs /sys/devices/system/cpu/cpuidle/current_driver` file. It must equal `intel_idle`. If it equals `acpi_idle`, only C0 and C1 will be used by the core.

Where to Find the Release

4

Go to the Intel® System Studio website (<https://software.intel.com/en-us/intel-system-studio>) to get either an Evaluation (30-day trial release) license or a commercial license, and download the package from the Intel Registration Center (<http://registrationcenter.intel.com/>).

Installation Notes

Intel SoC Watch for Linux* OS is available as part of Intel® System Studio. Use the steps below to install Intel SoC Watch on a target Linux system.

Intel SoC Watch Prerequisites for Yocto and Wind River* Linux

The Intel SoC Watch binary is a C++ program that requires libstdc++ to be present on the target system in order to function. Although most Linux distributions provide this by default, there are some minimal distributions of Yocto and Wind River Linux that may not.

To check if your OS image contains libstdc++, run this command:

```
find / -name "libstdc++"
```

If the library is present, you should see an output similar to:

```
/usr/lib64/libstdc++.so.6
```

If you see no output, the required library is missing. To fix this, do one of these steps:

- Rebuild Yocto or Wind River Linux with an option to include libstdc++.so file in the image.
- Provide the library file directly to Intel SoC Watch.

Rebuild OS image to include libstdc++.so file

1. Open the projectDir/local.conf file in a text editor.
2. Add the library with the IMAGE_INSTALL_append option and save the file:

```
IMAGE_INSTALL_append = " libstdc++"
```

NOTE Make sure that you include the leading space as it will be concatenated with any libraries previously added in a list.

3. Rebuild the platform project by running the following command from the projectDir:

```
make
```

Once the build completes, the library will be part of the project image rootfs. Proceed with reflashing the OS image to the target system and subsequently installing Intel SoC Watch.

Provide libstdc++.so library file directly to Intel SoC Watch

If you are unable to rebuild the OS image, but are able to obtain a valid libstdc++.so file (you can copy it from another system or build it yourself):

1. Unpack the SoC Watch package.
2. Copy the file into the /libs subfolder where it will be picked up at runtime.

libgcc_s.so Library

Some minimal Yocto distributions may also lack another library: libgcc_s.so. In this case, follow either of the aforementioned solutions.

Build the OS and include the image:

Use this command when building the OS.

```
IMAGE_INSTALL_append = " libgcc_s"
```

Copy file into Intel SoC Watch package:

Copy the library `libgcc_s.so` file into the `/libs` folder of the Intel SoC Watch package.

Extracting the Intel SoC Watch Package

You must extract the Intel SoC Watch package to the system containing the kernel of the target device.

By default you can find the Intel SoC Watch package here:

- On Linux systems: `/opt/intel/system_studio_<version>/energy_profiler_and_socwatch/socwatch_for_target`
- On Windows* systems: `C:\Program Files (x86)\IntelSWTools\energy_profiler_and_socwatch\socwatch_for_target`

Use the `find . -name Module.symvers` command on the device containing the target system's kernel to determine the kernel build directory.

Build the Kernel Modules

If the Intel SoC Watch kernel modules (i.e. device drivers) are not present in the OS image of the target system, you will need to build and possibly sign them. Building and signing device drivers requires access to the kernel build directory for the OS image running on your target device. A kernel build directory is generated while building the OS image of the target system.

When building the kernel modules, do not open (or unzip) the Intel SoC Watch package (i.e. `tar.gz` file) on a Windows* based system then copy to a Linux system. The package must be extracted on the Linux build system using the `unzip` command to make sure the build scripts and make files are unmodified.

If a kernel is built with the `CONFIG_MODULE_SIG` kernel config enabled, any device driver loaded into that kernel must be signed with the same keys used to build the kernel. In general, drivers built for Linux targets do not need to be signed and the following description assumes the drivers do not need to be signed. But, if an end user tries to load an unsigned driver into a kernel that requires signed drivers, the `insmod` command will fail with the error "Required key" not available. If a signed driver is loaded into a kernel that does not require signed drivers, the load will succeed.

The `build_drivers` script is provided to simplify building all of the drivers. The script supports multiple switches including:

```
-n // do not build the socperf driver; used for Intel® Core™ processor based systems
```

```
-l // build the kernel for a Linux target
```

```
-s <full path to sign-file> // signs the drivers; the path is normally ../kernel/*/scripts/sign-file
```

Building Linux* Kernel Modules

Linux kernel modules may only be built after the Intel SoC Watch package and kernel headers are copied to and installed on the target. See the section [Intel SoC Watch for Linux Installation](#) below for instructions on how to build the kernel modules for a target device running Linux.

Install Intel SoC Watch

Host: laptop, desktop, or server used to communicate with target device.

Target: device to be analyzed with Intel SoC Watch.

Intel SoC Watch for Linux* Installation

If Intel SoC Watch was previously installed on the target, delete the `socwatch_linux_*` directory before installing a new version. Then, perform the following steps on the target device.

1. Login to the target as root:

```
ssh root@<your_target_IP>
```

2. Extract the Intel SoC Watch package to the target Linux system. The `<extract_dir>/socwatch_linux_v<version>_x<architecture>` directory will be created.
3. Copy the Intel SoC Watch package to a working directory:

```
mkdir -p /home/socwatch
```

```
cp <extract_dir>/socwatch_linux_v<version>_x<architecture> /home/socwatch/.
```

4. Navigate to the Intel SoC Watch directory:

```
cd /home/socwatch/socwatch_linux_v<version>_x<architecture>
```

5. Use one of the following commands:

- a. If the target system has an Intel Atom® processor, use the following command to build the `socwatch2_10.ko` and `socperf3.ko` files.

```
sh ./build_drivers.sh -l -k <kernel-build-dir> -s <full-path-to-sign-file>
```

- b. If the target system has an Intel® Core™ processor, use the following command to build the `socwatch2_10.ko` file.

```
sh ./build_drivers.sh -l -k <kernel-build-dir> -n -s <full-path-to-sign-file>
```

Prerequisites for FPGA metric collection using Intel SoC Watch

Intel SoC Watch leverages Open Programmable Acceleration Engine (OPAE) drivers to collect data on supported FPGA platforms. OPAE drivers must be loaded on the system containing one of the supported FPGA architectures (see [System Requirements](#)) prior to running Intel SoC Watch collections. Source code for OPAE drivers may be downloaded from the OPAE GIT repository located at the following link: <https://github.com/OPAE/opae-sdk/releases>

The OPAE installation guide provides more information on the installation requirements for OPAE drivers. The guide may be downloaded from the following location: https://opae.github.io/latest/docs/install_guide/installation_guide.html.

Follow these instructions to build the OPAE drivers for your system:

1. Download the kernel headers to your system.
2. Download and extract the file starting with `opae-intel-fpga-driver*.tar.gz` to your system.
3. Go to the extracted directory, locate the file named `Makefile`, and run the `make` command in that directory.

This process will generate several files with a `.ko` extension. These are the OPAE drivers that need to be loaded to enable Intel SoC Watch collections. Load these driver files using the following commands:

```
sudo insmod fpga-mgr-mod.ko
sudo insmod intel-fpga-pci.ko
sudo insmod intel-fpga-fme.ko
sudo insmod intel-fpga-afu.ko
```

Key Files

The following table describes the key files.

File	Description
build_drivers.sh	The build script used to build all of the device drivers utilized by Intel SoC Watch.
socperf3.ko	The socperf kernel module used to measure bandwidth and DRAM self refresh on systems with an Intel Atom® processor.
socwatch2_x.ko	The Intel SoC Watch kernel module used to collect both hardware and kernel data at runtime.
setup_socwatch_env.sh	The script used to setup the Intel SoC Watch runtime environment.
socwatch	The Intel SoC Watch executable built as a native application. Use this file to collect data and generate additional results from a raw SW2 file.
SOCWatchConfig.txt	The Intel SoC Watch configuration file. The configuration file is read by Intel SoC Watch immediately before each collection. It contains hardware addresses utilized by the device driver during the collection.
EULA.txt	End User License Agreement file.
third-party-programs.txt	List of third party programs included in the package.
plugins/libSWCore.so	A library providing Intel SoC Watch functionality.

Remove the Intel SoC Watch Drivers

After using Intel SoC Watch, remove the drivers using the `rmmmod` command (e.g. `rmmmod socwatch2_10`). The `socwatch` driver must be unloaded before the `socperf` driver is unloaded.

Fixed Issues

The 2020.3 release has a fix for these issues.

- Fixed missing table reported by feature `-f pkg-pwr` when re-processing collection. Previously, the Package Limits table for `-f pkg-pwr` was not reported when using `-i` to re-process a result.
- Aligned report names for `-f acpi-sstate` to be the same across operating systems. The new name is "ACPI S-State". Previously, "Platform ACPI S-State" was used for Linux* OS and derivatives and "System S-State (OS)" was used for Windows* OS.
- Fixed `setup_socwatch_env.sh` script to determine the Intel SoC Watch installation folder using its own location. Previously, it used the current folder.
- Fixed issue where Intel SoC Watch would hang or crash when collecting many metrics and requesting multiple result file types (`-r`). Now you will see error messages indicating that too many files are open or the file system is not writable. To work around this issue, specify only one `-r` file type at collection time or collect fewer metrics. After collection, use `-i` option with each of the remaining file types to generate the additional result files.
- Removed irrelevant and/or duplicate information tables (i.e., Min/Max and Sample distribution) from the following metrics: `gt-temp`, `ia-temp`, `sa-temp`, `iunit-temp`, `pkg-temp`, `core-volt`, `die-temp`, `mod-temp`, `fpga-bw-write`, `fpga-bw-read`, `pmic-imon`.
- Fixed a discrepancy in `-f cpu-gpu-concurrency` metric that was causing the calculation for CPU-Only time to be wrong.
- Disabled integrated graphics metrics (`hw-igfx-cstate`, `hw-igfx-pstate`, `igfx-throt-rsn`, `cpu-gpu-concurrency`) when a discrete graphics card is installed and integrated graphics is disabled. A message is displayed to the console when `--help` is used to indicate when integrated graphics is disabled.

Known Issues

7

Bandwidth (on Intel Core Platforms)

- The presence of EDRAM on a system may not be detected by Intel SoC Watch. This is known to occur when the accelerator card VCA2, which contains EDRAM, is present.
- Total DDR bandwidth does not include EDRAM. On systems using EDRAM, the `ddr-bw` feature report may have a discrepancy between the total data reads and writes and the total component requests. The Data Reads+Data Writes will be significantly higher than the total IA+GT+IO requests, because the EDRAM requests are not included.

Bandwidth and DRAM Self Refresh (on Intel Atom® Platforms)

- On Intel platforms code named Apollo Lake and Gemini Lake, memory bandwidth and memory self-refresh metrics are not available. These features are not supported: `ddr-bw`, `cpu-ddr-bw`, `cpu-ddr-mod0-bw`, `cpu-ddr-mod1-bw`, `disp-ddr-bw`, `isp-ddr-bw`, `gfx-ddr-bw`, `io-bw`, `all-approx-bw`, `dram-srr`.
- Intel SoC Watch v2.10.0 and later versions require loading the `socperf` v3.0 driver to measure bandwidths or DRAM self-refresh on Intel platforms code named Cherry View, Broxton, and Apollo Lake. This version can automatically detect if the system is configured to support use of the hardware signals required to collect these metrics (`ddr-bw`, `gfx-ddr-bw`, `cpu-ddr-mod0-bw`, `cpu-ddr-mod1-bw`, `disp-ddr-bw`, `isp-ddr-bw`, `all-approx-bw`, `io-bw` and `dram-srr`). In older releases, these metrics were disabled completely on Apollo Lake platforms to avoid a system crash. If the system does not support these metrics, use `dram-bw` as an alternative for collecting bandwidth. Use the `-v` option to determine which version of the `socperf` driver is loaded. If a mismatch occurs (`socperf` v1.2.0 used with `socwatch` `>=v2.6.1`), Intel SoC Watch will report this error: `-1, SOCPERF ERROR configuring SOCPERF interface`.
- If Intel SoC Watch crashes while collecting a bandwidth feature (e.g. `-f ddr-bw`) or the DRAM self-refresh feature (i.e. `-f dram-srr`) AND a subsequent collection prints the error: `ERROR: ERROR configuring SOCPERF interface!` then both the `socperf3.ko` and `socwatch2_10.ko` kernel modules must be unloaded with the `rmmmod` command and reloaded with the `insmod` command before Intel SoC Watch can be used to collect additional data.
- When measuring DRAM self refresh using the `-f dram-srr` feature on cost reduced systems (e.g. Intel platforms code named CherryTrail cost reduced), Intel SoC Watch may report 100% self refresh residency on Channel 1. These systems are single channel systems and therefore, the result should be 0%.
- On a very small number of systems, results from the `all-approx-bw` feature may be one half of the correct result. During testing, this issue was only experienced on the first collection after the system was booted. All subsequent collections correctly measured the systems bandwidth as expected.
- If `socperf` reads occur before the start of collection, a `dmesg` error message is generated: `"socperf3: [ERROR] ERROR: RETURNING EARLY from Read_Data"`. This message is benign and can safely be ignored.

C-States / P-States

- When collecting a trace of residency data from hardware counters (i.e., using `-m`), the summarized residency data could be 2-3% inaccurate due to error propagation in the accumulation of each sample's calculated residency. Collecting without `-m` results in greater accuracy because only a single sample is taken. However, long collection duration could result in a counter rollover, and that will not be detected without the use of `-m`.
- The hardware CPU P-state data may be missing for some Cores when using feature `-f hw-cpu-pstate` on Intel platforms code named Skylake, Kaby Lake, Whiskey Lake, and Amber Lake. The issue is caused by unexpected behavior of the hardware counters. The tool ignores these bad samples which results in the missing data.

- On Intel platforms code named Broxton and Apollo Lake, the `cpu-cstate` metric results do not contain module C-state information.
- On Intel Atom[®] platforms, if all cores in a module request C6FS but actual sleep time is short, the Auto-Demotion logic of the hardware resolves the module state to module C0. Consequently, you may find module C0 to be greater than the sum of core C0 and C1 on all the cores in a module. On the same lines (auto demotion at the package level), the package C0 may be greater than module C0 residencies of the two modules.
- During the transition time from core C1/C1e/C6 to core C0, a core may run in LFM which will be properly measured by Intel SoC Watch. Therefore, results that include a large number of C1/C1e/C6 residencies may show a lower PState than expected.

S States & D States

- On Intel platform code named CherryView based devices:
 - Even when the device's screen is off, the NC DState called Display DPIO is reported in the D0i0 state 100% of the time. This result may or may not be correct.
 - When collecting NC D0ix states with the `-f nc-dstate` switch, note that the Display Island B (HDMI) IP block will remain in D0i0 when the primary display is enabled even if an HDMI cable is removed.
 - When using the `sc-dstate` feature, the SEC IP block results are incorrect and should be ignored. Also, the UFS IP block results are incorrect because an internal fuse is disabled.

Miscellaneous

- When running on Linux Yocto OS, SoC Watch will simply return without executing unless you create a symbolic link for `/lib64` pointing to `/lib`.
- If collecting a large number of metrics and requesting multiple types of results files to be generated on the same command line, SoC Watch may report the following, *Warning: Could not post process metric data: Too many open file handles. Results may be incomplete for some metrics. Try post processing results with only one -r option at a time. If the problem persists; try collecting fewer metrics.* There will be some missing reports in the results files that are generated if this occurs. The work around is to specify only one `-r` file type at collection time or collect fewer metrics. After collection, use `-i` option with each of the remaining file types to generate the additional result files.
- Feature `-f dram-pwr` is not supported by all versions of the server Intel platforms code named Skylake-Xeon, Cascade Lake-Xeon, and Denverton). The report contains all zero values in this case.
- Metrics report Unknown 0 when `-m` is not used and hibernation occurs. Metrics with a snapshot default collection mode, such as CPU C-state, will show the Unknown state with 0 time and the remaining states will not sum to the total collection duration if the system entered hibernation during the collection and the `-m` option was not specified. The snapshot metrics are only collected at the start and end of a collection by default, but finding hibernation time requires samples taken throughout the collection. Including `-m` will cause continuous sampling to occur for all metrics. When hibernation occurs, a message reporting time spent in hibernation appears at the beginning of the summary report. The Unknown state is then included for all appropriate metrics and the time in hibernation is included in that state. Refer to the *Intel SoC Watch User's Guide* "Options Quick Reference" section to learn which metrics have a snapshot collection mode by default.
- Intel SoC Watch reads PMIC and Skin Temperatures from the system's `sysfs`. Rarely, a `sysfs` read may not return before a subsequent `sysfs` read occurs. When this occurs, specific sample results may be missing in the timed trace CSV and raw text files.
- Permission issues with SELinux will cause Intel SoC Watch collection to fail. Some distributions enable SELinux by default. If you have the following file your system may have SELinux enabled:

```
/selinux/enforce
```

If that file exists, you can disable by issuing:

```
echo 0 > /selinux/enforce
```


- Syntax errors in the command line may not report a visible error message. If a collection did not run and you are not seeing any error message, add option `-d 2` to your command line to get more information.

Intel® VTune™ Amplifier Visualization

- The Intel VTune Amplifier System Summary does not report the rated frequency for the CPU when viewing results from data collected by SoC Watch, such as Throttling Analysis. Instead, it reports 1GHz which is the clock frequency used in the calculations for processing the SoC Watch data.
- Intel VTune Amplifier 2017 for Systems Update 1 or later is required for visualizing and analyzing Intel SoC Watch v2.10.0 and newer PWR files. We recommend using the latest version of Intel VTune Amplifier.
- If the bandwidth is 0 Mb throughout the collection for a particular bandwidth type, Intel VTune Amplifier will not show a timeline entry for it. The timeline is shown only if there is at least one non-zero value.
- In some cases, the summary CSV results produced by Intel SoC Watch can vary from the summary results shown by Intel VTune Amplifier even though they represent the same collection. For example, the summary CSV file may report a specific `cpu-pstate` residency of 50.78% and Intel VTune Amplifier may report the same `cpu-pstate` residency as 50.8%.
- Intel VTune Amplifier currently does not support bandwidth ranges used for `ReadPartial` and `WritePartial`. In order to keep the visualization consistent with Intel SoC Watch v1.x, Intel VTune Amplifier uses the upper bound of the range to visualize the bandwidth.
- The minimum and average calculations displayed in the grid for `Sampled Value` metrics don't take 0 values into consideration in older versions of Intel VTune Amplifier. For example, `Sampled Graphics P-States` minimum values may show a value higher than 0 Mhz even when some samples have 0 Mhz values. This in turn affects the average value calculation.
- In order to visualize graphics C-states that are reported as `Render` and `Media`, the table headers in the trace file (generated with option `-r int`), must be manually modified, adding *Render* and *Media* to the appropriate `C0`, `C1`, and `C6` column headers.

Related Documentation

The release contains these documents:

- Intel® SoC Watch for Android* OS and Linux* OS User's Guide
- Energy Analysis help (<https://software.intel.com/en-us/energy-analysis-user-guide>)